SRH150DT Assembly


Instructions and Procedures

Mar 10, 1995

UPDATES

• 3/28/95 ADDED 30000082 TO SLIDE 4 & 24


FZ038 Changes 2-27-95 Update 9:55am



Major Parts Required to MAKE ONE SRH150DT

- 2 IMH4100D MOBILE RADIO'S
- 1 HZ058 SR SERIES CABINET KIT
- 1 ARX725Z SR SERIES CONTROL BD
- 1 FZ038 SR SERIES POWER CORD KIT
- 1 35001183 SR SERIES POWER SUPPLY


Product Break-down




SRH150DT B.O.M.

| Item # | Part Number | Description | Quanty |
|--------|--------------|------------------------------|--------|
| 1 | IMH4100D | BASE MOBILE 150-174 MHz | 2 |
| 2 | ARX725Z | SR SERIES CONTROL BD | 1 |
| 3 | HZ058 | SR SERIES CABINET KIT | 1 |
| 4 | FZ038 | SR SERIES POWER CORD KIT | 1 |
| 5 | 35001183 | SR SERIES POWER SUPPLY | 1 |
| 6 | 30000082 | AC POWER SWITCH | 1 |
| 7 | 11000829 | GROMMET FOR SR SERIES RPTR | 1 |
| 8 | 11000815 | BLACK UNIVERSAL BUSHING | 2 |
| 9 | 11000745 | RUBBER BUMPER BLK SRH/SRU | 4 |
| 10 | 11000797 | #8-32 HEX NUT | 4 |
| 11 | 11000798F | #8-EXT LOC WASHER | 4 |
| 12 | 11000799F | #6-32 x 1/4 PAN HD MACH SCR | 12 |
| 13 | SSCW320604BF | SCREW FLT HD NO. 6-32 1/4" | 12 |
| 14 | SSCW530035NF | WASH: LOCK D3.5 NI (SMS815T) | 2 |
| 15 | BSPY0014002 | SPEAKER: (SRH/SRU) 8 ohm | 1 |
| 16 | 11001767 | SCR 2-56x3/8 PHIL MCH PANHD | 2 |
| 17 | 11001768 | NUT, 2-56 | 2 |
| 18 | 11000717 | #4-40 HEX NUT | 4 |
| 19 | AMX100A | REG. DUTY MIC (MK376) | 1 |


HZ058 SR SERIES CABINET



ARX725Z Control Board




ARX725Z Control Board




SOLDER SIDE VIEW

MODIFICATION 2-23-95




PRIOR TO ASSEMBLY

- UNPACK ALL IMH4100D's AND REMOVE THE MOUNTING BRACKETS (MINIMUM 200pcs.)
- SEND THESE BRACKETS TO GOLDEN MANUFACTURING IN GARLAND FOR REWORK




MODIFY THE RECEIVE UNIT IMH4100 LOGIC BOARD




IMH4100D TX PREPERATION

- a. PROGRAM ALL UNITS WITH CHANNEL 1-150.000MHz RX / 152.000MHz TX / CTCSS 179.9Hz
- b. REMOVE THE TOP AND BOTTOM COVERS
- c. NEXT REMOVE THE FRONT CONTROL HEAD (BE CAREFUL NOT TO DAMAGE THE FLAT RIBBON CABLE), UNPLUG SPEAKER FROM MAIN CHASSIS
- d. LABEL UNIT AS "TX MODULE"- PUT COVERS BACK ON


NOTE: YOU HAVE TO PROGRAM A DUMMY RECEIVE CHANNEL, OTHERWISE IT WILL NEVER TX.




Mount AMX725Z to HZ058




Inside Front View





Back View






Wiring the Power Supply







Finalize

- Send to Test
- Mount cover using 12pcs SSCW320604BF
 3 on each side / 3 on top / 3 on back
- Pack with AMX100A, Rack Mount Brackets and Mic clip (us from IMH4100) using ARX320 box w/die cut foam just like MRS804 series

SRU450KT Assembly


Instructions and Procedures

Feb. 17, 1995

Major Parts Required to MAKE ONE SRU450KT

- 2 IMU3100K MOBILE RADIO'S
- 1 HZ058 SR SERIES CABINET KIT
- 1 ARX725Z SR SERIES CONTROL BD
- 1 FZ038 SR SERIES POWER CORD KIT
- 1 35001183 SR SERIES POWER SUPPLY


Product Break-down




SRU450KT B.O.M.

| Item # | Part Number | Description | Quanty |
|--------|--------------|------------------------------|--------|
| 1 | IMU3100KT | BASE MOBILE 450-470 MHz | 2 |
| 2 | ARX725Z | SR SERIES CONTROL BD | 1 |
| 3 | HZ058 | SR SERIES CABINET KIT | 1 |
| 4 | FZ038 | SR SERIES POWER CORD KIT | 1 |
| 5 | 35001183 | SR SERIES POWER SUPPLY | 1 |
| 6 | 30000082 | AC POWER SWITCH | 1 |
| 7 | 11000829 | GROMMET FOR SR SERIES RPTR | 1 |
| 8 | 11000815 | BLACK UNIVERSAL BUSHING | 2 |
| 9 | 11000745 | RUBBER BUMPER BLK SRH/SRU | 4 |
| 10 | 11000797 | #8-32 HEX NUT | 4 |
| 11 | 11000798F | #8-EXT LOC WASHER | 4 |
| 12 | 11000799F | #6-32 x 1/4 PAN HD MACH SCR | 12 |
| 13 | SSCW320604BF | SCREW FLT HD NO. 6-32 1/4" | 12 |
| 14 | SSCW530035NF | WASH: LOCK D3.5 NI (SMS815T) | 2 |
| 15 | BSPY0014002 | SPEAKER: (SRH/SRU) 8 ohm | 1 |
| 16 | 11001767 | SCR 2-56x3/8 PHIL MCH PANHD | 2 |
| 17 | 11001768 | NUT, 2-56 | 2 |
| 18 | 11000717 | #4-40 HEX NUT | 4 |
| 19 | AMX100A | REG. DUTY MIC (MK376) | 1 |


HZ058 SR SERIES CABINET



ARX725Z Control Board




ARX725Z Control Board




SOLDER SIDE VIEW

MODIFICATION 2-23-95




PRIOR TO ASSEMBLY

- UNPACK ALL IMU3100K's AND REMOVE THE MOUNTING BRACKETS (MINIMUM 200pcs.)
- SEND THESE BRACKETS TO GOLDEN MANUFACTURING IN GARLAND FOR REWORK




MODIFY THE RECEIVE UNIT IMU3100 LOGIC BOARD




IMU3100K TX PREPERATION

- a. PROGRAM ALL UNITS WITH CHANNEL 1-450.000MHz RX / 462.000MHz TX / CTCSS 179.9Hz
- b. REMOVE THE TOP AND BOTTOM COVERS
- c. NEXT REMOVE THE FRONT CONTROL HEAD (BE CAREFUL NOT TO DAMAGE THE FLAT RIBBON CABLE), UNPLUG SPEAKER FROM MAIN CHASSIS
- d. LABEL UNIT AS "TX MODULE"- PUT COVERS BACK ON


NOTE: YOU HAVE TO PROGRAM A DUMMY RECEIVE CHANNEL, OTHERWISE IT WILL NEVER TX.




Mount AMX725Z to HZ058




Inside Front View





Back View






Wiring the Power Supply







Finalize

- Send to Test
- Mount cover using 12pcs SSCW320604BF
 3 on each side / 3 on top / 3 on back
- Pack with AMX100A, Rack Mount Brackets and Mic clip (us from IMU3100) using ARX320 box w/die cut foam just like MRS804 series